



| No. | Part name | Material | QTY | Remark |
|-----|-----------------|--------------------------|-----|--------|
| 01 | Cable | | 1 | |
| 03 | Upper cover | FC200 | 1 | |
| 07 | Stator | | 1 | |
| 09 | Shaft end | SUS420J2 | 1 | |
| 11 | Bearing fixer | FC200 | 1 | |
| 16 | Motor frame | FC200 | 1 | |
| 17 | Lubricant | | | |
| 18 | Outer cover | SS400 | 1 | |
| 19 | Bearing bracket | FC200 | 1 | |
| 20A | Bearing | | 1 | |
| 20B | Bearing | | 1 | |
| 21 | M.seal | SIC / SIC & SIC / SIC | 1 | |
| 23 | M. seal bracket | FC200 | 3 | |

| No. | Part name | Material | QTY | Remark |
|-----|-----------------|----------|-----|--------|
| 24 | Oil seal bush | SUS420J2 | 1 | |
| 25 | Oil seal | NBR | 2 | |
| 26 | Casing | FC200 | 1 | |
| 27 | Impeller | FC200 | 1 | |
| 28 | Casing cover | FC200 | 2 | |
| 29 | Wear plate | SUS304 | 2 | |
| 31 | Strainer | SS400 | 1 | |
| 43A | Moisture sensor | | 1 | |
| 46 | Impeller key | SUS304 | 1 | |
| 47 | Packing | | | |
| | | | | |
| | | | | |